



## WIFI/Bluetooth/GPS




## Camera




## RS232




## SRAM



## Ethernet



## MP3 Decode




## IRED




## DS18B20 & DHT11




## BEEP




## RS485




## ADC




## IO




## CPU




## TF/LCD




## POWER




## USB USART




## BOOT



## RESET



## JTAG




## LED




## KEY



## PWM DAC




## EEPROM




## Touch\_Key



## MPU6050



## Light\_Sensor



## NRF24L01



## SPI FLASH

