


TITLE PAGE (EXCLUDE)

		0-2351-333	OMS ESC		
--	--	------------	---------	--	--

FIND	PART#	PART DESCRIPTION	QUANTITY	TASK	TOOLING
1	45556-2342	Plate	4	Secure the Plate	Torque cross patternm



		0-2351-333	OMS ESC		
--	--	------------	---------	--	--



FIND	PART#	PART DESCRIPTION	QUANTITY	TASK	TOOLING
1	234234-234	Ring	2	SECURE insulator	Use the ring to secure the insulator
2	4534-325	Plier	4	Using the Plier	Use the plier carefully
3	43534-2354	Wrench	3	Using the Wrench	Use the wrench carefully