






RPi Motor Driver Rev 0.2
by Proteus Engineering


















To Do:

Only Connect RS232 Device is Board is Powered Down

⊗ ⊗ ⊗



Raspberry Pi

