

# Amazon Echo Dot



## Instructions and Useful Information

The Amazon Echo Dot connects to your home internet and a smartphone or tablet for setup. It has a microphone and speakers and listens to and answers questions after you wake it up with the word, "Alexa".



# Instructions

## Part 1: Signing into the Alexa App

*On a smartphone or tablet*



Install the Amazon Alexa app. The Amazon Alexa app is available in the Amazon App Store, Google Play, and the Apple App Store. Installing the app may require a password, finger print, or facial recognition authentication depending on your device settings.

Once the app has finished downloading and installing, open it up and sign in with a free Amazon account.

If you haven't created an Amazon account, go to <https://www.amazon.com> then hover over Account & Lists then select Start here and follow the instructions to create an account.

Once signed in to the app, go to your Settings and make sure the Alexa app has permissions to use Bluetooth. Alexa initially connects to your device over Bluetooth, a local wireless connection.

## Part 2: Getting the Alexa speaker ready

*With the Alexa device itself*

Plug one end of the included power adapter cord into an outlet and the other into the larger circular plug on the back of the Alexa device.

Wait as the device turns on and thinks.

# Instructions

## Part 3: Add and configure the Alexa speaker in the app

*On a smartphone or tablet*



- 1 Open the Alexa app.  
Go to the **Devices** section.




- 2 Select +.

- 3 Select: **Add Device Echo, Smart Home, and Accessories.**



- 4 Press **Amazon Echo** from the list. Press **Echo Dot** from the next list. Press **3rd Generation** from the last list.



*With the Alexa device itself*


- 5 On the device, make sure an orange light is spinning around the device. If it didn't do this on its own, press and hold the **grey dot Action button** until an orange light starts spinning around the device.

*On a smartphone or tablet*

- 6 If your device asks you if there is an orange light present, select **Yes**.
- 7 From the list that appears, select **Echo Dot-534**.



**8** On the Select your Wi-Fi Network screen, pick the Wi-Fi Internet network the device should connect to. In most cases, this should be the same Wi-Fi network that any smartphones, tablets, or laptop computers in your home also connect to. If that network has a password, your device will ask you to type it in. After you have entered this information, the device will connect to that network.



It may also ask you to describe where the Echo Dot is in your house, but you can simply press Skip. You can also skip teaching Alexa your voice, physical street address, and their introduction video.

## Part 4: Using the Amazon Alexa Echo Dot smart speaker

*With the Alexa device itself*

The Alexa speaker will tell you that it's updating. When it says, "Your Echo is ready," it's done updating and ready to use.

Check the insert for added information on using Alexa, including skills and tips to get the most out of this device.

**Questions?** Please give us a call at (224) 233-1841 or stop by for assistance.



# Using Alexa

By default, the Echo Dot device listens for a **wake word**. After hearing the wake word it more actively listens to whatever you say until you stop talking. Background noise can confuse Alexa. Speak loudly and clearly.

The default wake word is “**Alexa**”.

So you can say things like:

“Alexa, remind me on Saturday to go to the Library.”

“Alexa, what’s the weather like in Lincolnwood, Illinois?”

“Alexa, tell me the news.”

“Alexa, play jazz music.”

“Alexa, how many ounces are in a cup?”

“Alexa, what’s 20 degrees Celsius in Fahrenheit?”

“Alexa, how do you say ‘thank you’ in Hindi?”

“Alexa, add bread flour to my shopping list.”

## Skills

Alexa calls apps “skills”. Skills are made by third parties other than Amazon. Most skills are free, but some “premium skills” require payment.

You can ask Alexa about skills: “Alexa, what are your top skills?”

Or you can ask for skills by name. Many common services and sources of information have skills: “Alexa, open NPR” “Alexa, open CNN.” “Alexa, open Fox News.”

Each skill typically reads you its instructions and tells you how to use it. Listen carefully.

## Tips

For more ideas of what to do with this Echo Dot, open the Alexa app on your smartphone or tablet, go to the horizontal ||| menu and press Things to Try.

If Alexa is taking too long, you just need it to stop, or is going into too much detail about something, say: “Alexa, stop.”

To stop the device from listening to you, press the Ø button, or simply unplug it from power.

To increase volume, press the + button.

To decrease the volume, press the – button.