


***This wine cellar includes a stainless steel handle.***

***To install the handle please follow the below instructions:***



1. Pull away the door gasket in the area where the handle is to be installed on the left side as shown below in illustration #1.

The gasket can easily be displaced by hand, no tools are necessary.



2. Align the handle with the screws installed.

Tighten the screws using a Phillips head screwdriver until the handle sets both flush and secured tightly against the door frame. (**DO NOT** over tighten as this will cause damage to the handle assembly).




3. Replace the door gasket to its original position.





- 1. Gasket
- 2. Phillips Head Screw Driver
- 3. Phillips Head Screw
- 4. Handle

Cette cave à vin comprend une poignée en acier inoxydable.  
Pour installer la poignée, veuillez suivre les instructions ci-dessous :


1. Retirez le joint de la porte dans la zone où la poignée doit être installée sur le côté gauche, comme indiqué ci-dessous sur l'illustration #1. Le joint peut facilement être déplacé à la main, aucun outil n'est nécessaire.



2. Alignez la poignée avec les vis installées.  
Serrez les vis à l'aide d'un tournevis cruciforme jusqu'à ce que la poignée soit bien alignée et solidement fixée contre le cadre de la porte. (NE PAS trop serrer car cela endommagerait l'assemblage de la poignée).



3. Remplacez le joint de la porte dans sa position d'origine.



1. Joint de porte
2. Tournevis cruciforme
3. Vis cruciforme
4. Poignée
5. Vis