


15dB if a 100K resistor is connected between GAIN and GND
 12dB if GAIN is connected directly to GND
 9dB if GAIN is not connected to anything (this is the default)
 6dB if GAIN is conncted directly to Vin
 3dB if a 100K resistor is connected between GAIN and Vin



Sheet: /
 File: Console.sch

Title: Portable Emulator

Size: USLetter Date: 2019-12-28
 KiCad E.D.A. kicad (5.1.5)-3

Rev: 1
 Id: 1/1