

To/From Arduino

All column SRs have 300-Ohm resistors on pins QA-QH

