

Media Scheduler

status active

---

Media Scheduler

## Table of Contents

- [About](#)
- [Getting Started](#)
- [Installation](#)
- [Circuit](#)
- [Web App](#)
- [Usage](#)
- [List Of Components](#)
- [Built Using](#)
- [DemoVideo](#)
- [Authors](#)

## About

This repo contains

- Firmware
- Circuit
- Detailed instructions

for Media Scheduler.

## Getting Started

These instructions will get you a copy of the project up and running on your system. The flowchart of the system is given below:

### Prerequisites

Things you need to install the FW.


- 1x Raspberry Pi 3B or 4

## Installation

A step by step series that tell you how to get the Firmware and Backend running

### Raspberry Pi Zero W Configuration

1. Download and install Raspberry Pi Imager from here <https://www.raspberrypi.com/software/>
2. Download "Raspberry Pi OS with desktop and recommended software" from here <https://www.raspberrypi.com/software/operating-systems/>
3. Then extract the downloaded image file using any extraction software like 7-zip <https://www.7-zip.org/>
4. Put a 16 GB SD Card in your Laptop/PC.
5. Open the Raspberry Pi imager, Click on "Choose OS" button and scroll down to select "Use Custom" as shown below



6. Then select the extracted image file.
7. In the next step select your SD Card and then click on "Write" button to start the writing process.
8. That's it. It should be flashed within a few minutes.
9. Download this repository and open the configFiles folder of the repository and open wpasupplicant.conf file and add your WiFi credentials in it.

### Firmware Configuration

10. Once done, remove the SD Card and re-insert it into your PC/Laptop and then open the "boot" volume. Copy the files of "configFiles" folder here in the "boot" volume. Also create an empty file named "ssh" in the "boot" volume if not already present.

11. Do the same steps for 2nd SD Card as well.
12. Then put the SD Card in the first Raspberry Pi Zero and power it on.
13. Then SSH into the Raspberry Pi which you can using the command `ssh pi@raspberrypi.local`
14. Once you are logged in, execute the following command

## Auto Firmware Installer

To install and Run Media Scheduler Automatically just run the following command on your Raspberry Pi terminal

- `curl -sSL https://raw.githubusercontent.com/Nauman3S/Media-Scheduler/main/installer.sh | bash`

After the installer completes the process restart your raspberry pi.

## Running the Firmware

- `DISPLAY=:0 /home/pi/Media-Scheduler/Firmware/starter.sh`

## Disabling Raspberry Pi Boot Messages

1. Execute the following command

- `sudo nano /boot/cmdline.txt`

2. Change the console from tty1 to

`console=tty3`

3. Add this to the end of the line. `loglevel=0` removes most of the messages from the boot and put the following line at the end

`quiet splash loglevel=0 logo.nologo vt.global_cursor_default=0`

4. Press CTRL+O and CTRL+X to save and exit.

5. `sudo nano /etc/rc.local`

6. Add this before 'exit 0':

7. Press CTRL+O and CTRL+X to save and exit.

- `dmesg --console-off`

7. Execute the following command

- `sudo update-rc.d motd remove`

8. `sudo nano /boot/config.txt`

9. Add the following line at the end of the file

- `disable_splash=1`

10. Press CTRL+O and CTRL+X to save and exit.

11. `sudo nano /boot/cmdline.txt`

12. Add below line to end of file

- `logo.nologo`

13. Press CTRL+O and CTRL+X to save and exit.


14. `sudo reboot`

Following these 14 steps will remove all unwanted boot logs messages and raspberry pi logo/splash screens.

Circuit


Raspberry Pi Pinout

Follow the pinout diagram below to connect the components to the Raspberry Pi.



Alternate Function					Alternate Function
	3.3V PWR	1		2	5V PWR
I2C1 SDA	GPIO 2	3		4	5V PWR
I2C1 SCL	GPIO 3	5		6	GND
	GPIO 4	7		8	UART0 TX
	GND	9		10	UART0 RX
	GPIO 17	11		12	GPIO 18
	GPIO 27	13		14	GND
	GPIO 22	15		16	GPIO 23
	3.3V PWR	17		18	GPIO 24
SPI0 MOSI	GPIO 10	19		20	GND
SPI0 MISO	GPIO 9	21		22	GPIO 25
SPI0 SCLK	GPIO 11	23		24	GPIO 8
	GND	25		26	GPIO 7
	Reserved	27		28	Reserved
	GPIO 5	29		30	GND
	GPIO 6	31		32	GPIO 12
	GPIO 13	33		34	GND
SPI1 MISO	GPIO 19	35		36	GPIO 16
	GPIO 26	37		38	GPIO 20
	GND	39		40	GPIO 21

Complete Circuit



Components Pin Connection Details


Components pin connection details

Console Button

Console Button to open or close console

Button Pins	Raspberry Pi
PIN 1	GND
PIN 2	23

WebApp



Dashboard can be accessed using the credentials given below

- <https://mediascheduler-frontend.production.rehanshakir.com/>
- Email Address: admin@mediascheduler.com
- Passowrd: admin

## Dashboard Features

- Upload Pictures and set their display time and display duration.
- Upload videos and set their display time.
- Upload default picture which will be displayed when nothing else is running.(uploading a picture with name default.png will make it a default picture)

Backend Link: <https://mediascheduler-backend.production.rehanshakir.com/api/fields>

## Usage

1. Upload the code to your Raspberry Pi as mentioned in the [Installation](#) section above.
2. Now connect the circuit components as mentioned in [Circuit](#) section above.
3. Power on your raspberry pi.
4. Use the webapp dashboard to upload new videos/pictures.
5. To set a default picture, upload a image file named **default.png** and it will be automatically used as a default image.
6. Press the push button to open the terminal.

## List of Components

Following components are used to make this project

1. Raspberry Pi 4 Kit [Raspberry Pi 4 Kit](#)
2. Generic Push buttons

## Built Using

- [Python](#) - Programming Language
- [NodeJS](#) - JavaScript Framework for WebApp Backend
- [ReactJS](#) - JavaScript Framework for WebApp FrontEnd
- [MongoDB](#) - NoSQL Database for WebApp

## Demo Video

[Media Scheduler Demo](#) - Media Scheduler Demo Video

## Authors

- [@Nauman3S](#) - Development and Deployment