





Selecting program 1:

Press once button 1 to select first program.
First **red** LED is on.




Selecting program 2:

Press once more button 1 to select second program.
Second **red** LED is on.




Selecting program 3:

Press once more button 1 to select third program.
Both first and second **red** LEDs are on.





Press button 1 again to go back to program 1.



Running program:


Press once button 2 to start the previously selected program (program 1 here).

Familiarization phase: **Green** LED is on.



Running program:

CS stimulation: **Yellow** LED is on.



Running program:

US stimulation: Last **red** LED is on.

Note that CS and US are usually overlapping for some time (Cf. photo).

At the end of the program, last **red LED is blinking. When it stops, another program can be selected to start again.**