

**Push Button**  
**Function:**  
 Reset Sensor (Logger)  
 Start/Stop recording (Coordinator)

**Top Half of Case**

**Reset Button Pin Opening**  
**Function:**  
 Reset Sensor

**USB C Port**  
**Function:**  
 Charge Sensor  
 Sensor interactions

**Slide Switch**  
**Function:**  
 On/Off Switch

- 1: Arduino Nano ble 33
- 2: LiPo Battery
- 3: OpenLog Artemis
- 4: Slide Switch
- 5: Tactile Switch

**Bottom Half of Case**

**Top View**

**Top View**

**Bottom View**

**Back**

**Front**

**Side View**

**Front View**

**WMORE Case and Components**

Author: Sami Kaab

Date: 05/04/2023

Version: 1.0

Units: millimeters(mm)

