


## WLED Quick start guide

### Set the name and configure WIFI

1. Power up the WLED Controller.
2. Using a smart phone connect to the WIFI access point called **WLED-AP** using the password of **wled1234**.
3. Open a web browser to the IP address 4.3.2.1
4. You should see something similar to:



5. Click on **Config**.
6. Click on **User Interface**.
7. In the **Server Description** field, enter the name of the device so you know which is which if you have more than one.
8. Click on **Save**.
9. The main configuration menu should appear, if not, click on **Back**.
10. Click on **WIFI Setup**.
11. Under **Network Name** enter your **WIFI SID** and **Password**.
12. Click **Save and Connect**

In the event the settings need to be reset, press and hold the **DO** button for 10 seconds. The **WLED-AP** access point will start up and you can repeat the steps above.

The device is now connected to your WIFI. A web browser can be used to connect to the device, or an IOS / Android app can be used.

[https://play.google.com/store/apps/details?id=com.aircoookie.WLED&hl=en\\_US&gl=US](https://play.google.com/store/apps/details?id=com.aircoookie.WLED&hl=en_US&gl=US)

<https://apps.apple.com/kw/app/wled/id1475695033>