



Boot Mode Select

PG.1	PG.0	BOOT
0	0	USB
1	1	QSPI FLASH0