

Note: Install a *fixed* voltage regulator.
The adjustable voltage regulator does not work.

