



Assembly Items	Qty	Assembly Items	Qty
500-01 Base Plate	1	500-24S Shroud Screws	4
500-02 Motor Housing with Sharp Vac Plug	1	500-24W Shroud Washers	4
500-03 Shroud	1	500-25 Vise Bolt	1
500-04R Drive Pulley	1	500-26 Vise Washer	1
500-05 Hex Nut (Motor)	2	500-27 Stop Plate Bolt	1
500-06 Washer (Motor)	2	500-28 Stop Plate	1
500-07 Belt Drive	1	500-29 Pivot Post Screws	2
500-08 Set Screws (LG Pulley)	2	500-30 Stop Plate Nuts	2
500-09 Pivot Post Spring	1	500-31 Pivot Post Block	1
500-10 Set Screws (Pivot Post)	2	500-32A Vise Assembly (including Vise Handle)	1
500-11 Pivot Post Pin	2	500-33A Vise Stop & Locking Screw Assembly	1
500-12 Set Screws (SM Pulley)	2	500-34S Vise Stop & Locking Short Screw	1
500-13B Bolt for Handle	1	500-34L Vise Stop & Locking Long Screw	1
500-13W Washer for Handle	1	500-35 Dust Shield	1
500-14 Handle Grip	1	500-36 Filter Cap	1
500-15 Handle (tubing)	1	500-37 Filter	1
500-16 Minitul Label	1	500-38 Saw Shaft	1
500-17 Caution Label	1	500-39 Shaft bearings	2
500-17A Warning Label	1	500-40 Saw Shaft Nut	1
500-17B MicroGroup Label	1	500-41B Blade Flange	1
500-17C MOD500 Saw Serial Number	1	500-42 Wrench Set	1
500-18R Shaft Pulley	1	500-44 Foot Switch & Cord	1
500-20 Main Frame	1	500-45 Power Cord	1
500-21 Blade (see page 8)	1	500-46 Motor 1/5 H.P.	1
500-22 Lock Nut (stop screw)	1	500-47 Vise Handle	1
500-23 Stop Screw	1		