

GraphicPal IV (0604)

User's Manual

Hanwang Technology Co., Ltd.

Copyright © Hanwang Technology Co., Ltd, 1999-2016

All rights reserved. No part of this manual may be reproduced except for your express personal use. Hanwang Technology Co., Ltd reserves the rights to revise this publication without obligation to provide notification of such changes. Hanwang Technology Co., Ltd does its best to provide current and accurate information in this manual. However, Hanwang Technology Co., Ltd reserves the right to change any specifications and product configurations at its discretion, without prior notice and without obligation to include such changes in this manual.

GraphicPal and Hanvon are registered trademarks of Hanwang Technology Co., Ltd.

Microsoft, Windows, and Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Apple, the Apple logo, and Macintosh are registered trademarks of Apple Computer, Inc., registered in the U.S. and other countries. Any additional company and product names mentioned in this documentation may be trademarked and /or registered as trademarks. Mention of third-party products is for information purposes only and constitutes neither an endorsement nor a recommendation. Hanwang Technology Co., Ltd assumes no responsibility with regard to the performance or use of these products.

INTRODUCTION

Contents

Chapter 1 Graphics Tablet Introduction	3
1.1 General Introduction	3
1.2 Features.....	3
1.3 Quick-Start Tutorial.....	4
Chapter 2 Instruction for Windows Systems.....	11
2.1 System Requirements	11
2.2 Installation.....	11
2.3 Uninstalling	12
2.4 Configuration.....	13
Chapter 3 Instruction for Mac Systems	27
3.1 System Requirements	27
3.2 Installation.....	27
3.3 Uninstalling	31
3.4 Configuration.....	32

INTRODUCTION

Chapter 4 Bundled Software	39
4.1 Hanvon Shell	39
4.2 PenWrite	45
4.3 PenSign	52
4.4 PenMark.....	53
4.5 WhiteBoard.....	56
Chapter 5 Maintenance	60
5.1 Exchange Pen Nib	60
5.2 Cautions	60
Appendix.....	61
Warranty	61

This User's Manual provides quick access to information about Hanvon® Drawing Tablet or Hanvon® Graphics Tablet.

- ◆ This User's Manual does not contain detailed information of any software from third party.
- ◆ Due to our continuous updates on the product, all figures in this manual are only for reference, the actual item is the standard.

INTRODUCTION

- ◆ For latest updated user manual, please visit and download from <http://www.hanvon.com>.

Chapter 1 Graphics Tablet Introduction

1.1 General Introduction

The Hanvon Graphics Tablet allows you to create graphics on a computer using a cordless and battery-free digital pen. It is very easy to use. You don't need to be an experienced graphic artist to use it. This USB graphics tablet supports a variety of professional painting and photo editing software including Painter, Photoshop, Ulead PhotoImpact, Flash, Dabbler, Maya, PaintShop and more.


1.2 Features

- Express Keys and Touch Ring
- Uses standard USB without the need for an external power adapter
- Cordless and Battery-free Digital Pen

INTRODUCTION

- Pressure Sensitive Technology
- Eraser and Programmable Switches on Stylus
- Widescreen and Multiple Monitors Supported
- Vista/Windows7/8 Supported, Windows & Mac compatible
- Software Supported: Painter / Photoshop / Ulead PhotoImpact / Flash / CorelDraw / Dabbler / Maya and a variety of graphic processing software

1.3 Quick-Start Tutorial



INTRODUCTION




Holding the pen

Hold the pen as usual.

- The pen will take effect when it comes within 10mm above the tablet.
- While using the pen, be sure that your thumb or index finger can easily control the programmable buttons on the pen, which act as the “right-click” and “double-click” key of a mouse individually.

INTRODUCTION



Positioning

Moving the pen in the active area of the tablet will control the cursor's position on the computer screen.



The pen and tablet use the Absolute Coordination method. This means the active area of the tablet represents the entire

INTRODUCTION

computer screen. Moving the pen on the tablet creates a corresponding movement of the cursor on the screen.

Single Click

One slight touch of the pen on the tablet has the same effect as a single left-click of the mouse.



Double Click

Two immediate clicks on the tablet have the same effect as a double left-click of the mouse.

INTRODUCTION




Double Click Technique

When the cursor is positioned, press the tablet twice immediately with the pen tip, making sure that you do not move the pen tip. The response for the double click can be slow for beginners. You can solve this problem by adjusting the double click speed from the normal setting of the tablet.

Dragging

Select a target by pressing the pen down on it, and do not release the pen till you have moved the target to the new position you want.

INTRODUCTION



Pressure Sensitive Painting

With 2048 levels of pressure sensitivity, the drawing pen can sense tiny pressure from light hand. Let users work easily and comfortably like the feel of traditional painting, smooth drawing and brush stroke effects by pressing harder or softer with the digital Pen.

The software that supports pressure sensitivity includes Adobe Photoshop, Painter, Flash, Ulead PhotoImpact, Art Dabbler etc.

Express keys

Express Keys are programmable as function keys, keyboard shortcuts, mouse clicks, launching applications, and pop-up menus.

INTRODUCTION

User may zoom, scroll, change brush size, rotate canvas in applications by using finger sensitive Touch Ring.

Eraser and Programmable Switches on Stylus

Featuring Hanvon's Pressure Sensitive Technology, the stylus senses tiny pressure from Pen tip. Pressure Sensitive Eraser on stylus brings convenient tool to modify art work. Two programmable switches on pen body enable user to customize the function of switching according to user's habits.

INSTRUCTION FOR WINDOWS SYSTEMS

Chapter 2 Instruction for Windows Systems

2.1 System Requirements

CPU	Pentium III 1GHz or later
RAM	256MB
Hard-disk	150MB or above
OS	WINDOWS XP/Vista/7/8/8.1/10
Port	USB2.0 or above

2.2 Installation

Connect the drawing tablet's USB cable to the computer's USB port.

Step 1

Insert the driver CD into the CD-ROM drive. The Installation Menu should pop-up automatically. If the menu does not

INSTRUCTION FOR WINDOWS SYSTEMS

appear, double-click the *My Computer* icon on the Desktop, find the *AutoRun.exe* file under the CD-ROM's root directory, and double-click it.

Step 2

Click on *Install Driver for Graphic Tablet* button to install the driver and click on *Install Hanvon Soft* to install the bundled software.

Step 3

After installing the driver and the bundled software, read this manual for detailed information on using and customizing your graphics tablet.

Note: If the tablet cannot be used after driver installation, please restart your computer.

2.3 Uninstalling


Step 1

Click the Windows *Start* button and then select *Control panel*.

Step 2

Double click *Add/remove program* in the control panel window and find *Tablet Driver*.

INSTRUCTION FOR WINDOWS SYSTEMS



Step 3

Click *Uninstall* and follow the prompts to remove the tablet driver.


2.4 Configuration

Hanvon tablet driver provides a configuration window to set pen pressure, working area, dual-monitors, double-click speed, express touch keys, etc.

Before Configuration

- Connect the graphics tablet to the USB port on your computer.
- Go to *control panel*.

INSTRUCTION FOR WINDOWS SYSTEMS




- Double-click the *HW Tablet* icon to open the configuration interface.



INSTRUCTION FOR WINDOWS SYSTEMS

2.4.1 General Configuration





a. Adjusting Pressure Sensitivity

Pen pressure sensitivity can be adjusted by dragging the slider between soft and hard. To create broad strokes, use a soft tip. To draw thin lines, use a hard tip. The factory setting can be restored by clicking the *Default* button. Adjustments can be saved by clicking the *Save* button or can be canceled by clicking the *Cancel* button.

b. Pressure Curve Graph

Pen pressure sensitivity changes are displayed on the Pressure Curve Graph. The images below show the graphs for light and heavy pen pressure respectively.

INSTRUCTION FOR WINDOWS SYSTEMS




c. Pressure Testing Area

The right area is the pressure test area which is used to test the pen tip feel. The round circle at the upper left corner represents the tilt angle between the drawing pen and the tablet surface. All the writing and drawing in the test area can be cleared by clicking the *Clean* button.

Note: Only Windows 2000/XP/Vista/7/8/8.1/10 support tilt angle.

INSTRUCTION FOR WINDOWS SYSTEMS



d. Parameter settings

Parameter settings include Nib Pressure Sensitivity, Tilt Sensitivity, and Nib Click Sensitivity. The users can adjust the value to find comfortable operation. Click *Default* to restore the factory settings, click *Save* to save the current setting, click *Exit* to quit.


e. Soft Key Settings

There are two buttons on the Pen: the upper one is “Right Click” by default , the lower one is “double click”. Users can also set buttons to other functions from options in figures below.

INSTRUCTION FOR WINDOWS SYSTEMS

Left Key
Right Key
Middle Key
Double Click Key
Scroll Up
Scroll Down
Keyboard
Application
Disable

2.4.2 Mapping



a. Single Monitor Mode

The entire active area of the tablet maps to the entire monitor by default. If your computer has more than one monitor, see


INSTRUCTION FOR WINDOWS SYSTEMS

Multi-Monitor Mode.

b. Multi-Monitor Mode

a) Full Screen


Choose *Select Monitor* and then select *Full Monitor* from the drop-down menu. You will see the screen area corresponding to the active area of the tablet is mapped.



b) Screen #1


Choose *Select Monitor* and select *Monitor 1* from the drop-down menu to set the area, then only *Monitor 1* can be controlled by the tablet.

INSTRUCTION FOR WINDOWS SYSTEMS



c) Screen #2


Choose *Select Monitor* and select *Monitor 2* from the drop-down menu to set the area, then only *Monitor 2* can be controlled by the tablet.



INSTRUCTION FOR WINDOWS SYSTEMS

c. Portion of Screen

Choose *Part of Monitor*, and then click the upper left corner and lower right corner for the expected area of screen which will be mapped to the full tablet.



d. Auto Setting

The tablet active area can be automatically set by clicking the *Auto Setting* button to be 1:1 aspect ratio between tablet working area and the display.

Note: Auto Setting cannot be set in the mode of Part of Monitor.


e. Mapping All Tablet

Click the *All Tablet* button; driver will automatically adjust the

INSTRUCTION FOR WINDOWS SYSTEMS

active area of the tablet mapped to the whole screen.

2.4.3 Express Keys Setting




There are many Express Keys on the tablet. Please see the default function in the bellow picture. The users also can define them to other special functions. The Touch Ring on the tablet is for quick scrolling, zooming, controlling brush size, and enable rotated.

a. Define the function of express keys

There are eight express keys on the tablet. When you

INSTRUCTION FOR WINDOWS SYSTEMS

configure the key function, there are two ways to define it. One is to choose the options from the drop-down menu for each key, and then click **Save** to save the setting.





Another way is defined by pressing the keyboard of your computer. After that, click **Save** to save the setting or click *Cancel* to discard the changes.

Example 1

If you want to assign CTRL+A to one of the express keys, select the key you want to set, then press CTRL and A simultaneously on the computer keyboard.




INSTRUCTION FOR WINDOWS SYSTEMS



Example 2

Select *Application* from the drop-down menu then *Utility* will pop up automatically. Click *Select* button and choose one application program you want to run then click *OK*.


INSTRUCTION FOR WINDOWS SYSTEMS



INSTRUCTION FOR WINDOWS SYSTEMS

Example 3


Express key can be disabled by choosing *Disable* from the drop-down menu.



The default setting of Touch Ring is enabled. If want to disable it, please click the *Enable/Disable* button.

b. Double-Click speed setting

Open *Hanvon Tablet* folder in *All Programs*. Choose *Mouse Setting*, then users can drag the slider to adjust the double-click speed and scope, and test the setting on the folder icon.



INSTRUCTION FOR MAC SYSTEMS

Chapter 3 Instruction for Mac Systems

3.1 System Requirements

RAM	256MB
Hard-disk	200MB
OS	MAC-OS 10.6 or later
Port	USB2.0 or above

3.2 Installation

Connect the graphic tablet's USB cable to the computer's USB port.

Step 1

Insert the driver CD into the CD-ROM drive then find the install file in *MacOS X* folder, click on the *Install.dmg* icon to run the file.

INSTRUCTION FOR MAC SYSTEMS



install.dmg

Step 2


Double-click the *Install* icon.



Install

Step 3


Click *Continue* in the reminder window.



Step 4

Please read the license agreement carefully then click *Continue*. After that click *Agree* to continue the installation.


INSTRUCTION FOR MAC SYSTEMS



Step 5


Click *Install* to install the tablet driver.

INSTRUCTION FOR MAC SYSTEMS



Step 6


When the install process is finished, please click *Logout* and reboot your computer.



INSTRUCTION FOR MAC SYSTEMS

3.3 Uninstalling

Open *HWTablet* folder in *Applications*. Choose *Uninstall* to remove the tablet driver.



Please click **OK** when the driver has been removed.
(Suggestion: Reboot the computer) .




INSTRUCTION FOR MAC SYSTEMS


3.4 Configuration

Connect the tablet to your computer by USB cable and port.

The *HWTblt* icon has been added in the applications. Double-click the *HWTblt* icon to open the tablet control panel.



3.4.1 General Configuration





INSTRUCTION FOR MAC SYSTEMS

a. Adjusting Pressure Sensitivity

Pen pressure sensitivity can be adjusted by dragging the slider between *soft* and *hard*. The right area is the pressure test area. Adjustment can be saved by clicking the *Save* button, or can be canceled by clicking the *Cancel* button.

b. Pressure Curve Graph


Pen pressure sensitivity changes are displayed on the Pressure curve graph. The images below show the graphs for light and heavy pen pressure respectively.



c. Pressure Testing Area

The right area is the pressure test area which is for testing the pen pressure. All the writing and drawing in the test area can be cleared by clicking the *Clear* button.


INSTRUCTION FOR MAC SYSTEMS



3.4.2 Mapping

a. Multi-Monitor Mode


You can drag the displays to the desired order if your computer has more than one monitor.



INSTRUCTION FOR MAC SYSTEMS


a) Full screen

Choose *Region Setting* and select *Total Monitors* from the drop-down menu. You will see the active area of the monitors corresponding to the area in table is mapped.



b) Monitor #1


Select *Monitor #1* from the drop-down menu to set the area in the tablet to control Monitor #1.



INSTRUCTION FOR MAC SYSTEMS

c) Monitor #2



Select *Monitor #2* from the drop-down menu to set the area in the tablet to control Monitor #2.



3.4.3 Express Keys Setting


a. Express keys


There are eight express keys on the tablet. You can set the functions for each key from each drop-down menu in *Key Setting*. Click *Save* to save the setting or click *Cancel* to quit.




INSTRUCTION FOR MAC SYSTEMS

You can select *Launch Application* from the drop-down menu, then choose one application program you want to run, click *open* and then click *Save* to save the setting.



You can also define the function by choosing  from the drop-down menu for each key and select shortcut from the *Key Bindings*.

INSTRUCTION FOR MAC SYSTEMS



BUNDLED SOFTWARE


Chapter 4 Bundled Software

4.1 Hanvon Shell

4.1.1 Shell Summary

Hanvon Shell is a shortcut startup application for starting bundled Hanvon Software or other software.

Default startup style: it will be operated automatically when you startup your computer; if user exits shell from the application, it will switch to the manual startup style; double

click the shortcut icon on the desktop  to startup the Shell toolbar.

Main interface will be shown as following:



Icons explanations as following:

BUNDLED SOFTWARE

1. Area for Dragging Shell

After opening shell toolbar, you can drag the icon to adjust the positions at up, down, left and right locations on computer's screen;

When cursor have been left the toolbar for 5 seconds or later, Shell toolbar will be hided, Single-click it to display the main interface;

2. PenWrite

Editing Microsoft Office documents formatted as: Word, Txt, Excel and PPT by handwriting directly;

PenWrite Provides English, German, French, Italian, Dutch, Spanish, Swedish, Portuguese (Portugal), Portuguese (Brazil) multi-languages recognition

3. PenWrite Asia

Editing Microsoft Office documents formatted as: word, txt, Excel and PPT by handwriting directly;

PenWrite Asia Provides Simplified Chinese, Traditional Chinese (Hong Kong) , Traditional Chinese (Taiwan), Japanese and Korean languages recognition

BUNDLED SOFTWARE

4. PenSign

This program enables you to add your handwriting signature in a document such as Microsoft Office word /PPT;

5. PenMark

Providing handwrite mark on desktop or pictures;

6. WhiteBoard

A software application simulates Electronic Whiteboard. The monitor is like a marker board in front of users and become a simplified Electronic Whiteboard through a projector.

7. System Menu

Configure shell setting

8. Tablet Setting

Configure tablet setting


4.1.2 System Menu Shell



Click  to enter Shell configuration interface shown as

BUNDLED SOFTWARE

following figure:



Position: Set the position for Hanvon Shell on the screen;

Icon Size: Set the icon size shown in the Hanvon startup toolbar;


Transparency: Set the transparency for Hanvon startup toolbar.

BUNDLED SOFTWARE

4.1.3 Tablet Setting




Click to enter tablet setting interface shown as following figure:



BUNDLED SOFTWARE

4.1.4 Shell right key menu



Delete: Delete the current icon or separator;

Options: Change name and icon of the current software

Location: Find the target file position which the software is saved

Add Separator: Add the separator in the location where the cursor is placed.


Setting: (the function is the same as System Menu)

Next Page: Turn to next page

BUNDLED SOFTWARE


4.2 PenWrite



Click  on the shell to open **PenWrite** application.

Open WORD application for editing, Then users may handwriting input words, sentences, punctuation & symbol and numbers **in English, German, French, Italian, Dutch, Spanish, Swedish, Portuguese (Portugal), Portuguese (Brazil).** The handwriting characters would be turn to be text automatically to the location where the cursor was placed.



Click  on the shell to open PenWrite Asia application. Open WORD application for editing, Then users may handwriting input characters, punctuation & symbol and numbers in Simplified Chinese, Traditional Chinese (Hong Kong) , Traditional Chinese(Taiwan) , Japanese and Korean.


Note: Please confirm the cursor's location firstly, and then start handwriting.

PenWrite and PenWrite Asia have the same main interface.

Instruction as following:

BUNDLED SOFTWARE

Icon explanations:



Basic functions

1. Pen & Mouse Mode

Switch the status between Pen & Mouse Mode



\ Pen Mode



\ Mouse Mode



2. Comma & Period

Edit", " or "." by clicking



Comma or



Period

3. Backspace

Backspace by clicking



4. Enter

Enter by clicking



5. Keyboard

BUNDLED SOFTWARE




Click to startup software keyboard

6. System Menu



Click to enter an interface shown as following figure:



7. Exit



Click to exit


8. the candidate area for recognized results

Setting

Click “setting...” shown as following figure:

✧ **Setting for PenWrite—Recognition**

BUNDLED SOFTWARE




[Select Language] Choose recognition language between 9 different languages;

[Recognition Range] Choose the recognition range;

[Recognition Delay] Adjust the recognition interval time.

BUNDLED SOFTWARE


✧ Setting for PenWrite Asia—Recognition



[Select Language] Choose recognition language between Simplified Chinese, Traditional Chinese (Hong Kong) , Traditional Chinese (Taiwan) , Japanese and Korean. [Recognition Range] Choose the recognition range;
[Recognition Delay] Adjust the recognition interval time.

✧ Setting—Pen

BUNDLED SOFTWARE




Selecting the pen type, line colors or line thickness

✧ **Gesture:**

① Space, ②Backspace, ③Enter, ④Tab

BUNDLED SOFTWARE



✧ **Edit Command:**

 =Ctrl

For example:



Ctrl+A



Ctrl+X

Edit Command supported as bellow:

Ctrl + A

Ctrl +C

Ctrl +V


Ctrl +X

Ctrl +Z

BUNDLED SOFTWARE


4.3 PenSign



Click  to open PenSign application

- The program can be used in Microsoft Office 2000 and the version higher, Word, Excel, PowerPoint (Notice: please don't write directly in Word outline\Excel pagination preview\ PowerPoint insert images);
- Support the Word Pad and Windows Draw (when the script will be shown opacity, it wouldn't support "Hide Sign & Show Sign" and "Delete Sign" functions) .
- The signature size and position can be adjusted freely.

Icon explanations:




1. Start Sign & End Sign;
Start and end to sign;
2. Pen(Brush \ pencil \ Ink Pen)
Select pen type
3. Color

BUNDLED SOFTWARE

- Select line color
- 4. Width
 - Select line thickness
- 5. Clear all
 - Clear current script
- 6. Hide Sign & Show Sign
 - Show or hide your signature
- 7. Delete Sign
 - Delete all script
- 8. System Menu
 - Help & About
- 9. Exit

4.4 PenMark

Click  to open PenMark application; you can handwrite marks on the screen or pictures.



Icon explanations:

1. Start/exit screen annotation
2. Open picture

BUNDLED SOFTWARE

3. Save
 - Files can be saved as BMP, JPG, TIF, PNG or GIF format
 - Suggest you to select TIF format when the file has several pages.
 - Default saving path: C:\Documents and Settings\Administrator\My Documents\My Pictures.
4. Pen(Brush \ pencil \ Ink Pen\ High Lighter)
Select Pen type
5. Color
Select line color
6. Width
Select line thickness
7. Eraser
Clear part script
8. Clear all
Clear all script
9. Tools
Insert line\figure\text\pictures

BUNDLED SOFTWARE




10. System Menu

Setting, Help, About

11. Exit

Setting



Setting the size of eraser

BUNDLED SOFTWARE

4.5 WhiteBoard



Click  to open WhiteBoard application.



Icon explanations:

1. Save
 - The document can be saved as BMP, JPG, TIF, PNG or GIF format
 - Suggest you to select TIF format when the document has multiple pages.
 - Default saving path: C:\Documents and Settings\Administrator\My Documents\My Pictures.
2. New Page

Add a new page
3. Pen (Brush \ pencil \ Ink Pen\ High Lighter)

Select pen type
4. Color

Select line color
5. Width

Select line thickness
6. Eraser

BUNDLED SOFTWARE


Clear part script

7. Clear all

Clear all script

8. Tools

Insert Line\figure\text\pictures




9. Magnifier

- Click the right key, the menu will popup, you can set spotlight size, shape, radio, high quality display, show border and exit
- Exit the application directly by pressing ESC

10. Spotlight



- Click  down arrow, the menu will popup, you can set spotlight transparency, shape and exit.
- Exit the application directly by pressing ESC

11. System Menu

Setting, Help, About

BUNDLED SOFTWARE

12. Previous

Turn to previous page


13. Next

Turn to next page

14. Exit

Setting


✧ Setting--Magnifier



Setting magnifier size, shape, ratio, high quality display and show border


✧ Setting—Spotlight

BUNDLED SOFTWARE



Setting spotlight transparency and shape

✧ Setting—Eraser




Setting the size of eraser

MAINTENANCE

Chapter 5 Maintenance

5.1 Exchange Pen Nib

If users need to change pen nib, please using tweezers, grasp the nib and draw it out. Once removed, a new nib may be inserted into the pen.



5.2 Cautions

Do not put the tablet on a metal surface, such as iron or aluminum alloys.

Due to a CRT monitor's electromagnetic radiation, do not use the drawing tablet too close to a CRT monitor.

APPENDIX

Appendix

Warranty

Limited Warranty

Hanvon Corporation warrants that this product is free from any defects in workmanship or materials under normal use and conditions for a period of two (2) years for Europe and one (1) year for other region from the date of original purchase. If such a defect is discovered within this warrant's limitations, Hanvon agrees, at its sole discretion, to repair or replace the same item with one of equal value, free of charge to the original consumer purchaser.

This warranty shall not apply if this product is modified, misused, tampered with, subject to abnormal working conditions, or transferred to someone other than the original consumer purchaser.

Warranty Redemption for US Market Only

Should this product fail to function in a satisfactory manner, please return it to the store where it was originally purchased. Please be sure to contact us at tech@hanvon.com.cn to

APPENDIX

obtain a Return Merchandise Authorization Number before you return it, and within your email please include your name, address, phone number, a copy of the original receipt, serial number and the reasons for returning the product.

Should this fail to resolve the matter and service is still required by reason of any defect or malfunction during the warranty period, Hanvon Corporation will repair or replace this product without charge (except for a charge for handling, packing, return UPS/postage, and insurance).

APPENDIX



- **GraphicPal III**

Professional Graphics Tablet for Artists and Professional Users

- **Features**

- **Cordless & Battery-free Pen Technology**

The drawing pen is light weighted and easy to use without unwanted hassle of batteries or wires

Pressure Sensitive Technology

With 2048 levels of pressure sensitivity, the drawing pen can

APPENDIX

sense tiny pressure from light hand. Let users work easily and comfortably like the feel of traditional painting, smooth drawing and brush stroke effects by pressing harder or softer with the digital Pen.

APPENDIX

- Technical Specifications

Model No.	GP3S (Small)
Active Area (LxW)	6"x4" (152.4 x 101.6mm)
Pressure Level	2048 levels
Resolution	3000 lpi
Pen Tilt Range	±60°
Tablet Size (LxWxH)	268*175*9.2mm
Max. Reading Height	7+ mm
Max. Report Rate	150 pps
Accuracy	±0.1 mm
Programmable Express Keys	4
Interface	USB
Operating Temperature	5°C-40°C
Storage Temperature	-20°C-60°C
Storage Humidity	30%-85% (40°C)

APPENDIX

Power Requirement	5V,100mA
-------------------	----------

- * Specification subject to change without notification.

- ## System Requirements

- **Windows:**

Windows 2000/XP/Vista/7

Pentium III 1GHz or above

Minimum RAM: 128MB (recommended 256MB or above)

150MB of available hard-disk space

CD ROM drive

An available USB port

Mac:

Mac OS 10.5 or above

Minimum RAM: 128MB (recommended 256MB or above)

150MB of available hard-disk space

CD ROM drive

An available USB port