



26 23 31 30 G 3.3

3.3 G 30 31 20 27





			29	22	21	20	14	18	17	16	15	14	13
5	G	3.3	✓	✓	✓	✓	✓	✓	✓	✓	✓	LED 4	Switch 2
24			25	26	27								
		3.3	✓	✓	✓	✓	✓	✓	✓	✓	✓		
		28	29	30	31	32	33	34	35	36	37		
	0	1	2	3	4	5	6	7	8	9	10	11	12
G	✓	M1 C1	M1 C2	M1 B	M1 F	✓	✓	M2 C1	M2 C2	M2 B	M2 F	Switch 1	LED 2

M1

M2

G 3.3 30 31 6 5 G

LED 3 - Rx



LED3 - Rx

ESP 37

21	SDA	25	ML1
22	SCL	26	ML2
18	L1	27	MR1
19	L2	14	MR2
23	L3		
32	B1		
33	B2		

