



Button#1 -> D33  
Button#2 -> D34  
Button#3 -> D35  
Button#4 -> D36  
Button#5 -> D37  
Button#6 -> D38



MIDI OUT -> D1  
Pin 4 to 220 ohm resistor to 5V.  
Pin 2 to GND  
Pin 5 to 220 ohm resistor to D1



fritzing