



Note: The Rotary Encoder works as follows:

- When the Knob is turned to a latching position, both Switches (SW1 and SW2) will be closed or opened.
- When the knob is turned clock-wise, then SW1 will close / open first, then SW2 will close / open right after, but before the next latching position is reached.
- When the knob is turned counter-clockwise, then the SW2 will open / close first, then SW1 will follow before the next latching position is needed.

PhiSch.org

Sheet: /  
File: BlinkenBike.sch

**Title: BlinkenBike**

Size: A4 Date: 2020-10-12  
KiCad E.D.A. kicad (5.1.7-0-10\_14)

**Rev: r1.x**  
Id: 1/1