




Reset after overheating First Class 2 & 3



If the machine is not freezing and the red light is on next to the main power switch then it is likely that the condensing radiator is dirty.



Remove the side cover by taking out the two screws at the bottom.



Use a dish brush to clean the cooling fins or if possible compressed air or a vacuum cleaner.



Reset button is on the underside of the machine in the back left corner. Place your hand between the counter and the machine push the switch up.

NB: On older machines the reset button is inside the back cover

Blendz

0800264948