


Keep the lint filter clean!



On the side of your machine is a lint filter left hand side for BB2 and right hand side for BB1.

If it looks like this the machine cannot breath and will run hot! This can cause serious damage and will instantly void your warranty.



Remove the filter and clean regularly with warm soapy water.

You should be able to see through it when held up to the light.

Behind the lint filter is the condensing radiator.

This should also be kept clean so the air can flow through it.

Use a dish brush, a vacuum if you have one handy or even better compressed air from a can or compressor.



Blendz 0800264948

