

User Manual - MAGENTA

Equipment


- WiFi
 - Air conditioning
 - Heating
 - Electrical panel
 - Coffee machine
 - Induction hob
 - Dishwasher
-

WiFi

- Network name: Portapalace
 - Password: portapalaceamarena
-

Air Conditioning

- **Location:** Bedroom
- Turn on using the ON/OFF button.
- Adjust the temperature with the +/- buttons on the remote control.
- Adjust fan speed with the FAN button.
- For heating, select the “sun” symbol using the “Mode” button.



Heating

- **Type:** Independent with thermostat.
- To turn on the thermostat, press the sun button in the top right corner and adjust using the left arrows. The mode must always be set to the sun. To turn off, press the OFF button at the bottom right.



Electrical Panel

- **Location:** Wall to the right of the entrance.



Coffee Machine

- **Nespresso:** Turn on the coffee machine by pressing the cup button near the water tank.
- When the blinking stops, the machine is ready to dispense coffee.
- Place the cup under the spout and press the cup button to dispense coffee.
- It stops automatically.



Induction Hob

- Select the desired temperature using the two knobs at the bottom of the hob (right for the upper plate, left for the lower plate).



Dishwasher

- **Location:** Lower level of the kitchen.
- The switch is located to the right of the sink.

