

Bluetooth Speaker User Manual

Section 1: Introduction





Welcome to Your Bluetooth Speaker

Thank you for choosing this Bluetooth speaker. Compact yet powerful, it's designed to bring immersive sound wherever you go. This manual will help you set it up, use it effectively, and troubleshoot any issues.

Included in this manual:

- Setup and connectivity
 - Feature overview
 - Troubleshooting
 - Care and support
-

Section 2: What's in the Box

-  Bluetooth Speaker
-  USB Charging Cable
-  Quick Start Guide & Warranty Card
-  AUX Cable (optional, varies by model)

 If anything is missing, contact customer support or the place of purchase.

Section 3: Safety Precautions

1. Usage Tips

- ✓ Keep away from water unless IP-rated.
- ✓ Avoid placing near heat sources.
- ✓ Do not block speaker grills.

2. Charging Safety

- ✓ Use only the included or approved cable.

- ✓ Charge in a dry environment.
- ✓ Disconnect after full charge.

3. Handling & Storage

- ✓ Store in a cool, dry place.
 - ✓ Keep away from dust and magnetic items.
 - ✓ Turn off when not in use.
-

Section 4: Getting Started

4.1 Charging the Speaker

1. Connect the USB cable to a power source.
2. Plug the other end into the speaker's charging port.
3. Indicator lights up red (charging), turns off or blue when fully charged.


4.2 Pairing via Bluetooth

1. Long press the power button to turn on.
2. Activate Bluetooth on your phone or device.
3. Select your speaker from the device list.
4. Successful pairing is confirmed by a sound or solid LED.

 **Tip:** Your speaker will auto-pair with the last connected device.

Section 5: Controls & Features

- **Power Button:** Press and hold to turn on/off
- **Play/Pause:** Single press the multi-function button (MFB)
- **Volume +/-:** Tap to adjust sound level
- **Track Change:** Long press volume buttons for next/previous
- **Answer/End Calls** (if supported): Press MFB during incoming call

 **Tip:** Some models support voice assistants via double-tap.

🔧 Section 6: Troubleshooting Guide

❓ Common Issues & Fixes

- **No Sound:**
 - ✓ Check volume on both speaker and device
 - 🔧 **Fix:** Reconnect via Bluetooth or try AUX mode
- **Speaker Not Pairing:**
 - ✓ Ensure device Bluetooth is on and in range
 - 🔧 **Fix:** Reset Bluetooth by turning speaker off/on or clearing pairing history
- **Distorted Audio:**
 - ✓ Lower volume slightly or move device closer
 - 🔧 **Fix:** Check if battery is low or try another audio file
- **Not Charging:**
 - ✓ Use a different USB cable or power adapter
 - 🔧 **Fix:** Clean charging port and retry

💡 Tip: Reset speaker by holding MFB and Volume Up for 10 seconds (varies by model).

🔋 Section 7: Battery & Maintenance

- Charge fully before first use
- Avoid letting battery drain to 0% often
- Clean speaker grills gently with a soft brush
- Keep away from water unless explicitly waterproof


💡 Tip: Store at 50% battery if unused for extended periods.

📞 Section 8: Warranty & Support

- **Warranty:** Typically 1 year (varies by brand)
- Covers manufacturing defects only

Support Resources:

- Official website for drivers, firmware, or manuals
- Email/phone support details on the warranty card
- Save your receipt for easy warranty claims

 You're all set to enjoy music on the move with your Bluetooth speaker. Keep this manual handy for future reference!