


GX16-4 Connector



Switch 0 : Ryobi B charge via CON-B
Switch 1 : Power to Ryobi-A and charge via CON-A
Switch b : Power to Ryobi-B and charge via CON-B

LiPo Charger

