



Scale 1" = 200'

Mapbook location

10	25	40	55	70
9	24	39	54	69
	1			

Contact the substation operating  
personal for current switch positions

Published 01/06/04

page 1 of 1

4 KV  
RIVERSIDE SUB  
Manual Recloser

CIRCUIT  
14

