































































































CRESTRON AV lower case

 `	 1	 2	 3	 4	 5	 6	 7	 8	 9	 0	 -	 =	from left: LIVE, RSS, WIFI, BLUETOOTH, USB, TV, PROJECTOR, POWER, BATTERY POWER, MENU, GUIDE, PLAY, PAUSE
 q	 w	 e	 r	 t	 y	 u	 i	 o	 p	 []	 \ 	from left: STOP, REC, FFWD, RRWD, PLAY/PAUSE, NEXT TRACK, PREV TRACK, SLOW FWD, SLOW RWD, EJECT, REJECT, END, START
 a	 s	 d	 f	 g	 h	 j	 k	 l	 ;	 '			from left: TOP, BOTTOM, JUMP FWD, JUMP BACKWARD, FIRST, LAST, VOLUME RAISE, VOLUME DECREASE, VOLUME MUTE, MIC, MIC MUTE
 z	 x	 c	 v	 b	 n	 m	 ,	 .	 /				from left: EXIT, DELETE, RETURN, FAVS, FAVS2, SHUFFLE, REPEAT, REPEAT ONE, REPLAY, REFRESH

CRESTRON AV upper case

 ~	 !	 @	 #	 \$	 %	 ^	 &	 *	 ()	 _	 +	from left: THUMBS UP, THUMBS DOWN, ZOOM, HOME, FULL-SCREEN, RED, GREEN, YELLOW, BLUE, POWER ON/OFF, TIMED POWER OFF, MORNING, NIGHT
 Q	 W	 E	 R	 T	 Y	 U	 I	 O	 P	 {	 }	 	from left: DISPLAY, STRETCH VERTICAL, STRETCH HORIZONTAL, PIP, SWITCH SCREEN, SWITCH SOURCE, LOCK ASPECT, ZOOM IN, ZOOM OUT, MUSIC, MOVIE, PICTURES
 A	 S	 D	 F	 G	 H	 J	 K	 L	 :	 "			from left: VIDEO CONFERENCE, AUDIO CONFERENCE, PHONE, HANG-UP/DO NOT DISTURB, PHONE 2, CAMERA, DISC, DISC CHANGER, HEADPHONES, RF, BLU-RAY
 Z	 X	 C	 V	 B	 N	 M	 <	 >	 ?				from left: SATELLITE, RADIO, VIDEO GAME, STREAMING VIDEO, STREAMING AUDIO, COMPUTER, COMPUTER 1, COMPUTER 2, WINDOWS COMPUTER, MAC COMPUTER