

# HP Media Center Remote Control - IR Codes

HP P/N: 5070-1006; RC6 Protocol; RC6 Address: 0x4



Button	Description	Equiv. Keybind	RC6 Cmd (hex)
1	DVD Menu	Ctrl+Shift+M	24
2	Power	Sleep	C
3	Teletext		5A
4	Red		5B
5	Green		5C
6	Yellow		5D
7	Blue		5E
8	Record	Ctrl+R	17
9	Play	Media Play	16
10	Stop	Media Stop	19
11	Fast Rewind	Media Rewind	15
12	Pause	Media Pause	18
13	Fast Forward	Media Forward	14
14	Skip to Previous	Media Prev	1B
15	Skip to Next	Media Next	1A
16	Back	Backspace	23
17	Info / Menu	Ctrl + D	F
18	Nav. Up	Arrow Up	1E
19	Nav. Left	Arrow Left	20
20	Nav. OK/Enter	Enter	22
21	Nav. Right	Arrow Right	21
22	Nav. Down	Arrow Down	1F
23	Volume +	Media Vol + / F10	10
24	Volume -	Media Vol - / F9	11
25	Media Center	Win+Alt+Enter	D
26	Mute	Media Mute / F8	E
27	Channel +	Page Up	12
28	Channel -	Page Down	13
29	Television	Ctrl+T	25
30	Program Guide	Ctrl+G	26
31	TV Recordings	Ctrl+O	48
32	1	1	1
33	2	2	2
34	3	3	3
35	4	4	4
36	5	5	5
37	6	6	6
38	7	7	7
39	8	8	8
40	9	9	9
41	*	*	1D
42	0	0	9
43	#	#	1C
44	Clear	Backspace	A
45	Print	Ctrl+P	4E
46	Enter	Enter	B