



EXP1	
BEEPER	BTN_ENC
LCD_BLK	LCD_RST
TOUCH_CS	TOUCH_INT
LCD_CS	LCD_RS
GND	BOARD_5V

EXP2	
MISO	SCK
BTN_EN1	NC
BTN_EN2	MOSI
NC	RESET
GND	BOARD_3.3