



AHRS = Attitude and Heading Reference System
GPS = Global Positioning System
INS = Inertial Navigation System
OFS = Optical Flow Sensor

* Point where data is transferred to P0 as
rudder, aileron, elevator, and throttle values.

Yaw angle is held at starting position and does not affect position PID