




Current Sensor 1
Slave Address: 1000001




Current Sensor 3
Slave Address: 1000011




Current Sensor 2
Slave Address: 1000010




Current Sensor 4
Slave Address: 1000100




Current Sensor 5
Slave Address: 1000000




Battery Protection Unit 1




5V Boost Converter for Magnetorqueours




C-Type USB Input




Power Monitoring Unit




Battery Charging Unit




Battery Connectors



Solar Input



BUS



GND Pads