



- All pins of ports P1 and P2 can be used as an interrupt source.
- Capacitive sensing is enabled by setting PxSEL=0 and PxSEL2=1.

Leipzig University of Applied Sciences
Faculty of Engineering
Robert Fromm
published under Creative Commons BY-SA
July 2020