



Only install INA219AIDR in place of blue or purple INA219 board
Circuit from <https://github.com/adafruit/Adafruit-INA219-Current-Sensor-PCB>

