



Behringer X32 Preset Loading Instructions:

Instructions for Loading on the Behringer X32:

The X32/M32 has 100 available channel preset slots in the library. The console ships default with a preset library, if you would like to back those up, please see the “Backup of Original Preset Library” section to retain a backup of the original presets and any that you have added.

- Load the uncompressed preset library ('Behringer X32 Channel Presets' folder) onto a USB drive
- Take that USB drive and place it into the USB slot at the top of the console.
- Press the 'Library' button & page select over to the 'CHANNEL' page
- Press the 'Utility' button (it should light up green & provide a hidden menu)
- Scroll to Preset 01.
- Press the 5th rotary knob under the 'USB Drive Import'
- Navigate to the folder that you saved the preset library on the USB drive from step 1
- Press the 2nd rotary knob under 'All'
- Press the 6th rotary knob under 'IMPORT'

Backup of Original Preset Library:

- Take a USB drive and place it into the USB slot at the top of the console.
- Press the 'Library' button & tab over to the 'channel' tab
- Press the 'Utility' button (it should light up green & provide a hidden menu)
- Press the 3rd rotary knob under 'Select All'
- Press the 6th rotary knob under 'USB Drive Export'

Instructions for Loading into X32-Edit:

To load the presets into your X32-Edit software. One thing to note is that loading the presets into X32-Edit does not load the presets onto your X32 mixer. The following instructions is for loading the presets into the software.

- Load the uncompressed preset library ('Behringer X32 Channel Presets' folder) onto your computer
- Open X32-Edit, press 'Library', click on the 'Channel' tab.
- Select Preset 01
- Press Import
- Navigate to where you saved the Channel Preset Library to.
- Select all of the presets.
- Press 'Open' or 'Load' depending on your computer operating system.

If you don't want to overwrite one of the settings when loading onto a channel, make sure that item is not highlighted in orange in the recall scope before pressing load. For instance, if you wanted to load all except the EQ, after selecting the desired preset, press the EQ box on the right side of the screen so it is not highlighted. Now when the channel preset is loaded, it will overwrite only the boxes that are highlighted of the selected channel.