


R7 is normally open when AMS1117-3.3 is installed and using a 5V power connection on J3
Don't install AMS1117-3.3 and short R7 or install a 0 Ohm resistor to connect J3 3.3 volts (LiFePO4 Battery) directly to board 3.3v connections



Sheet: /
File: RTL8720DN multi function board.sch

Title:

Size: A Date:
KiCad E.D.A. kicad (5.1.5)-3

Rev:
Id: 1/1