

	AS15	AS15-2
Controller	Teensy 4.1	Teensy 4.1
Receiver	SimpleRTK2B	SimpleRTK2B
Receiver Port	8	8
IMU Port	5	5
Relay Control	No relays	No Relays
Motor Dir	23	23
Motor PWM	22	22
Power Relay	0	
Steer Relay	7	7
Steer Switch	26	26
Work Switch	27	27
Speed Pulse	28	
Pulse Cal		
RS232 Port		1