

Normal mode



Key	Strip turned on	Strip turned off
1	Brightness +	-
2	Brightness -	-
3	Off	-
4	Settings mode (press twice in 5secs)	On
5-11	Change color (Static or Pulse)	-
13-14		
17-19		
21-23		
12	Change music effect	-
15	Change color to custom one	-
16	Change replication amount	-
20	Change strip selection	-
24	Change smooth effect color	-

Settings mode



Key	Strip turned on
1	Backlight maximum +
2	Backlight maximum -
3	Off (and leave settings mode)
4	Leave settings mode
5	Manually add 5 to red
6	Manually add 5 to green
7	Manually add 5 to blue
8	Load custom color
9	Manually reduce 5 from red
10	Manually reduce 5 from green
11	Manually reduce 5 from blue
12	Save custom color
13	-
14	-
15	-
16	Toggle 'shiftOneRight'
17	-
18	-
19	-
20	Manually save settings to EEPROM (Only 100,000 write cycles!)
21	-
22	-
23	Toggle keystroke showing (green flash)
24	Reset all settings to defaults