

VisuCoreDataSlope - **Slope** values for all frames. To get the real value y for a pixel x the following calculation must be performed $y = \text{slope} * x + \text{offset}$. A real value could be a T2 value for images generated by the Image Sequence Analysis tool (see [chapter 0-2](#)).