




SIP Power Connections




Blueberry Tau OSD3358-SM
Rev. 0


SIP I/O Configuration



Board Primary I/O




Board Secondary I/O




SIP Boot Config


```
MMC1 > MMC0 > UART0 > USB0
```



External SD Card



DEBUG I/O



Board ESD Protection

