


1. LOCK SHOOT LIGHTS
2. HEAD UP DISPLAY (HUD)
3. ANGLE OF ATTACK INDEXER LIGHTS
4. LEFT ENGINE FIRE WARNING/EXTINGUISHER LIGHT
5. MASTER CAUTION LIGHT
6. LEFT WARNING/CAUTION/ADVISORY LIGHTS
7. HUD VIDEO CAMERA CONTROL
8. RIGHT WARNING/CAUTION/ADVISORY LIGHTS
9. AUXILIARY POWER UNIT FIRE WARNING/EXTINGUISHER LIGHT
10. RIGHT ENGINE FIRE WARNING/EXTINGUISHER LIGHT
11. CANOPY INTERNAL JETTISON HANDLE
12. MASTER ARM PANEL
13. LEFT DIGITAL DISPLAY INDICATOR (DDI)
14. UPFRONT CONTROL PANEL (UFC)
15. RIGHT DIGITAL DISPLAY INDICATOR (DDI)
16. MAP GAIN/SPIN RECOVERY PANEL
17. EMERGENCY JETTISON BUTTON
18. HUD CONTROL PANEL
19. STANDBY MAGNETIC COMPASS
20. STATION JETTISON SELECT

INSTRUMENT PANEL



21. LANDING GEAR AND FLAP POSITION LIGHTS
22. INTEGRATED FUEL/ENGINE INDICATOR (IFEI)
23. HEADING AND COURSE SET SWITCHES
24. HORIZONTAL INDICATOR (HI)
25. STANDBY ATTITUDE REFERENCE INDICATOR
26. AZIMUTH INDICATOR (BLANK PANEL SOME AIRCRAFT)
27. STANDBY AIRSPEED INDICATOR
28. STANDBY ALTITUDE
29. STANDBY RATE OF CLIMB INDICATOR
30. ENVIRONMENT CONTROL LOUVERS
31. LANDING GEAR HANDLE AND WARNING TONE SILENCE BUTTON
32. SELECT JETTISON BUTTON
33. BRAKE ACCUMULATOR PRESSURE GAGE
34. EMERGENCY AND PARKING BRAKE HANDLE
35. DISPENSER/ECM PANEL
36. RWR CONTROL INDICATOR (BLANK PANEL SOME AIRCRAFT)
37. CLOCK
38. RUDDER PEDAL ADJUST LEVER
39. COCKPIT ALTITUDE
40. STATIC SOURCE SELECT
41. RADAR ALTITUDE
42. AIRCRAFT BUREAU NUMBER
43. ARRESTING HOOK HANDLE AND LIGHT
44. LANDING CHECKLIST AND WING FOLD SWITCH
45. FLIGHT COMPUTER COOL SWITCH
46. CAUTION LIGHTS PANEL (GEN TIE ON AIRCRAFT 162394 AND UP)
47. HYD 1 AND 2 PRESSURE INDICATOR

ADA520-352-1-043

Figure FO-3. Front Cockpit F/A-18C/D Aircraft 163427 thru 163782
(Sheet 1 of 2)