

COMMAND CODE AND DESCRIPTION

CODE	DESCRIPTION
RST	Reset alarm system through code without pushing the reset button physically
CFG	Get all current configuration
L1	Turn ON the light
L0	Turn OFF the light
N1	Enable command reply notifications
N0	Disable command reply notifications (You cannot receive a feedback)
M1	Enable motion detections capability in PIR sensors
M0	Disable motion detections capability in PIR sensors
BAL	Inquire current LOAD balance
REG#<NETWORK PROMO>	Register any promo code <div> <div>EXAMPLES:</div> <div> REG#GOUNLI REG#GOCOMBOEEA20 GLOBE </div> <div> -register GOUNLI promo in GLOBE -register GOCOMBOEEA20 promo in GLOBE </div> </div>
SET#	Set phone number as feedback recipient <div> <div>EXAMPLES:</div> <div> SET#09093220001 received any feedback of the GSM </div> <div> -phone number 09093220001 will </div> </div>
GET#	Get saved recipient number