



Unilever
PRO

Powerful floor degreaser and cleaner



**Safely remove
grease and food
stains on floors in
just 10 seconds****

Case size

3 x 5L

POWERFUL GREASE AND FOOD STAIN REMOVAL

KEY BENEFITS



Cleans floors in 10 seconds**



No need to rinse



Food safe*



Fragrance free



Removes deep and difficult grease



AREAS OF APPLICATION



Kitchen floors



Tiles



Painted surfaces

HOW TO USE

DILUTE USAGE



STEP 1

Pour 100 ml of Handy Andy Floor Degreaser and Cleaner in 5 L of water.



STEP 2

Clean and wipe with the diluted mixture. For shinier results, wipe with a dry cloth.

NEAT USAGE



STEP 1

Pour on a wet sponge or directly on the surface.



STEP 2

Clean and wipe clean. For shinier results, wipe with a dry cloth.

*Food Safe indicates that the product is safe to use on food preparation areas if usage instructions on back of pack are followed. This is supported by the certification provided by Intertek, an external company that performed the analysis on: Toxicological Safety for Use in Direct Food Contact Applications (SANS 1828).

**As per lab test. Tested and approved by nrccs. Nrccs/8054/211025/1266.

**PROFESSIONAL
CLEANING MADE SIMPLE**



unileverprofessional.co.za

Follow us for more cleaning tips,
advice, and information

Discover our range

Scan me

