

Hub Switch (runs the layer 3 routing code, usually located in secondary flash)

VE10 -> 10.0.0.253/24

Ethernet 1/1/1

DHCP TRUST

Ethernet 1/1/3

UNTRUSTED

Ethernet 1/1/5

UNTRUSTED

10.0.0.38/24

DHCP Server
TFTP Server
SSH Server
Workflow Composer (BWC)

172.16.140.25/24

Chrome Web Browser

Blank config
Switch #1

Blank config
Switch #2

Brocade Workflow Composer with
Campus_ZTP pack installed