


# FM RADIO



“R” button resets the frequency to 88MHz. This is the beginning of the FM range. Press the “T” button, the module scans for the next available radio station. Press the **ON** button in the website and press the “R” button of **FM Module**. Now press the “T” button and FM module scans for an available radio station. When a station is found, it locks on to it and you hear it on the speaker. Press “T” button again for the next radio station. The module will scan up to 108MHz, the end of the FM band, and stop. You must then press the reset “R” button to start at 88MHz again.