



Upgrade steps:

1. The PC computer and XDM2041 connected by RS232 cable (you have to choose a PC has RS232 port)
2. Install the driver, there is a driver instruction. (PC software USB driver install guide), please follow it to install the driver.
3. Double click DS_Wave_Patch_1.17.7.v20191126_Setup.exe
4. Choose the corresponding COM (you can go to PC management to look for the corresponding COM), see below screenshot



5. Choose OS and the file of **XDM1041_OS_V2.1.2_20210525.bin**



6. Turn off the XDM2041 and then turn it on
7. Choose “begin to download” to begin the upgrade
8. After upgrade, the version number is V