




Cylindricity error for all z-positions




Cylindricity error at z_pos = 1




Cylindricity error at z_pos = 2



Cylindricity error at z_pos = 3



Cylindricity error at z_pos = 4



Cylindricity error at z_pos = 5

