



1) DS18B20 may be used, but need to rotate part by 180 degrees, Vcc is on different pin. Install R12 when using DS18B20.