



CAUTION
The following GPIOs are strapping pins.

GPIO2
GPIO8
GPIO9

There use can affect the ESP32 during booting.
See datasheet for details.



Pin Types

Power
Digital I/O
Analogue Input
SPI
UART
Ground