






U1A AT91SAM3SXC



U1C AT91SAM3SXC






U1B AT91SAM3SXC



Copyright Tinkerforge GmbH 2011.
This documentation describes Open Hardware and is licensed under the CERN OHL v.1.1.
You may redistribute and modify this documentation under the terms of the CERN OHL v.1.1. (<http://phn.org/cernohl>). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.1 for applicable conditions

powersupply.sch	stack.sch	bricklets.sch
Copyright (©) 2011, B.Nordmeyer <bastian@tinkerforge.com> Licensed under CERN OHL v.1.1		
Tinkerforge GmbH		
File: master.sch		
Sheet: /		
Title:		
Size: A4	Date: 12 jan 2012	Rev: 1.1
KiCad E.D.A.	Id: 1/4	





Copyright (©) 2011, B.Nordmeyer <bastian@tinkerforge.com>
Licensed under CERN OHL v.1.1

Tinkerforge GmbH

File: stack.sch

Sheet: /Stack/

Title:


Size: A4

Date: 12 jan 2012

Rev: 1.1

KiCad E.D.A.

Id: 3/4



Copyright (©) 2011, B.Nordmeyer <bastian@tinkerforge.com>
Licensed under CERN OHL v.1.1

Tinkerforge GmbH

File: powersupply.sch

Sheet: /Powersupply/

Title:

Size: A4

Date: 12 jan 2012

Rev: 1.1

KiCad E.D.A.

Id: 4/4