

## Solved problem:

- 1, GPS version, send GPS information automatically, sometimes comes with the problem of PTT can't transmit
- 2, The frequency band setting problem

## Firmware description:

Following two are for the version of 120.000 contacts

RT3S(CSV-GPS)-P19.06.bin(start from P) for GPS version for RT3S GPS version

RT3S(CSV)-V19.06.bin(start from V) for common version for RT3S No GPS version

## Upgrade step:

Simultaneously press side key 1 and PTT key to turn on the radio, the indicator blinks and open upgraded software





And then click the “Open Update File” button to select correct Update file, then click the “Download Update File” button to update, the radio will be upgraded as following:



正在升级软件.....


BOOT Download

User Program

ID

## Software description:

1. Login to the official website: <https://www.retevis.com/>
2. Move the mouse to "SUPPORT" and select the drop-down menu "Resources", then find the RT3S programming software and firmware click to download





## USB Driver

[USB Universal Driver >](#)[RT3&RT8 USB Driver >](#)[HD1 USB Driver >](#)

<a href="#">HD1</a>	<a href="#">HD1 GPS</a>	<a href="#">HD1 Firmware</a>	<a href="#">HD1 GPS Firmware</a>
<a href="#">RT1</a>	<a href="#">RT15</a>	<a href="#">RT2</a>	<a href="#">RT20</a>
<a href="#">RT21</a>	<a href="#">RT22</a>	<a href="#">RT23</a>	<a href="#">RT24</a>
<a href="#">RT25</a>	<a href="#">RT26</a>	<a href="#">RT27 License-free</a>	<a href="#">RT27-Licensed users only</a>
<a href="#">RT27V</a>	<a href="#">RT28</a>	<a href="#">RT29</a>	<a href="#">RT3</a>
<a href="#">RT3-GPS</a>	<a href="#">RT3 Firmware</a>	<a href="#">RT3S</a>	<a href="#">RT3S Firmware</a>
<a href="#">RT40-FRS</a>	<a href="#">RT40-PMR</a>	<a href="#">RT5/RT5R/RT5RV</a>	<a href="#">RT50</a>
<a href="#">RT50 Firmware</a>	<a href="#">RT51</a>	<a href="#">RT6</a>	<a href="#">RT7</a>
<a href="#">RT8</a>	<a href="#">RT8-GPS</a>	<a href="#">RT8 Firmware</a>	<a href="#">RT80</a>
<a href="#">RT81</a>	<a href="#">RT82</a>	<a href="#">RT82 Firmware</a>	<a href="#">RT83</a>
<a href="#">RT84</a>	<a href="#">RT87</a>	<a href="#">H777</a>	<a href="#">H777S</a>
<a href="#">RT6S</a>	<a href="#">RT90</a>	<a href="#">RT90 firmwareV6.03</a>	<a href="#">RT9000D</a>