

MCN Signal Routing

MTR_AIR_PRES1	AIN-1
MTR_PLATE_TEMP1	AIN-2
MTR_PLATE_TEMP2	AIN-3
MTR_AIR_PRES2	AIN-4
STRN1_X	AIN-5
STRN1_Y	AIN-6
STRN1_XY	AIN-7
STRN2_X	AIN-8
STRN2_Y	AIN-9
STRN2_XY	AIN-10
MTR_CLNT_TEMP	AIN-11
M/C_CLNT_TEMP	AIN-12
CLNT_FLOW	GP0



