








## MCN Signal Routing

|               |        |
|---------------|--------|
| REAR_SUSP     | AIN-1  |
| REAR_BRK_PRES | AIN-2  |
| 12V_SHUNT     | AIN-3  |
| DC_DC_TEMP    | AIN-5  |
| SPARE1_5V     | AIN-6  |
| SPARE2_3V     | AIN-7  |
| SPARE3_3V     | AIN-8  |
| 12V_SENSE     | AIN-9  |
| 12V_STANDBY   | AIN-10 |
| REAR_WSS      | GP0    |
| FRAME_FAULT   | GP1    |



Board: Rear MCN Breakout Version 1.0  
 Drawn by Victor Brechbill  
 Revision date: 04/02/15  
 Last modified date: 4/9/2015 12:09:15 PM